

## **DNA Knowledge Base**

### **Titan solenoid in cab switch wiring diagram**

As a precautionary measure, you may consider adding a fuse between the direction switch and the 12V supply from the battery.

A larger version of this diagram can be downloaded in the attachments area at the bottom of this page.

<https://help.dnaoffroad.com.au/questions/45/>