DNA Knowledge Base

Titan solenoid in cab swtich wiring diagram

As a precautionary measure, you may consider adding a fuse between the direction switch and the 12V supply from the battery.
A larger version of this diagram can be downloaded in the attachments area at the bottom of this page.

https://help.dnaoffroad.com.au/questions/45/