

DNA Knowledge Base

Warn XD9000i wiring diagram

Open the attachment at the bottom of the screen to see XD9000i wiring diagram.

The power-in solenoids have the small green wires attached to them (green is power-in, black is power-out).

<https://help.dnaoffroad.com.au/questions/61/>